
How to upgrade the firmware of an NVR/DVR using a USB Thumb Drive

Important Note: The USB drive must be in FAT32 format. Place only one firmware file on the USB. Avoid storing multiple firmware versions to prevent upgrade conflicts.

Method 1: Automatic Upgrade

1. Copy the firmware file to the root directory of a USB drive (do not rename the file).
2. Power off the device.
3. Insert the USB flash drive into the USB port of the NVR/DVR.
4. Power the device back on.

Method 2: Manual Upgrade via UI

1. Copy the firmware file to the root directory of the USB drive (do not rename the file).
2. Insert the USB drive into the NVR/DVR.
3. On the device UI, go to System > Maintenance > FW Update.
4. Select the upgrade file and proceed.
5. The system will reboot automatically after the upgrade is successful.

